X-NOVA

Manual de partes

Alpha C
Un lazo para toda la vida.

TRIME

FLOODLIGHTS (JAGUARO)_PROIETTORI (JAGUARO)_LÁMPARAS (JAGUARO)



N.	CODE	DESCRIPTION
1	AC000_P037_005	CAP
2	PFM08_C000_038	CENTERING ROD SUPPORT
3	LED00_C000_006	CENTRAL SUPPORT
4	PFM08_C000_071	WHITE PLATE
5	PFM08_C000_070	LOGO PLATE
6	PFM08_C000_072	RED PLATE
7	AC000_E026_140	FLOODLIGHT
8	AC000_M000_076	HANDLE
9	LED04_C000_012ZN	SPACER
10	LED04_C000_092ZN	FLOODLIGHT SUPPORT
11	AS000_M023_001	SPACER
12	AS000_E006_029	JUNCTION BOX
13	PFM08_C000_045	JUNCTION BOX COVER
14	AC000_E018_008	PG11 CABLE GLAND
15	AC000_E018_002	PG21 CABLE GLAND

STEEL ROPES AND PULLEYS_FUNI IN ACCIAIO E PULEGGE_CUERDAS Y POLEAS DE ACERO



N.	CODE	DESCRIPTION
1	AC000_M021_009	STEEL ROPEL.4300mm
2	AC000_M021_006	STEEL ROPE L.1415mm
3	AC000_M021_013	STEEL ROPE L.1460mm
4	AC000_M021_011	STEEL ROPE L.1455mm
5 (*)	AC000_M021_002	PULLEY D.60
	AC000_M021_003	PULLEY D.62
	AC000_M021_008	PULLEY D.63
6	AS000_M000_029	SCREW

(*)	PLEASE AT THE TIME OF THE ORDER MEASURE THE DIAMETER MISURARE IL DIAMETRO AL MOMENTO DELL'ORDINE MEDIR EL DIÁMETRO EN EL MOMENTO DE LA ORDEN

MAST_PALO_MÁSTIL



N.	CODE	DESCRIPTION
1	PFM08_C031_092	MAST ROTATION PLATE
2	PFM08_C000_094	MAST PLATE
3	AC000_M038_007	RUBBERED CLAMP
4	PFM08_C000_138ZN	LOWER PLATE FOR SPIRAL CABLE
5	XNOVA_C007_008ZN	FRONT PLATE FOR MAST POSITIONING
6	AC000_E006_258	SPIRAL CABLE
7	PFM08_C000_137ZN	UPPER PROTECTION FOR SPIRAL CABLE
8	AC000_M000_271	WINCH
9	PFM08_C000_006ZN	6TH MAST SECTION
10	PFM08_C000_005ZN	5TH MAST SECTION
11	PFM08_C000_004ZN	4TH MAST SECTION
12	PFM08_C000_003ZN	3RD MAST SECTION
13	PFM08_C000_002ZN	2ND MAST SECTION
14	PFM08_C031_100ZN	1ST MAST SECTION
16	XNOVA_C007_009ZN	REAR PLATE FOR MAST POSITIONING
17	AC000_M000_271_01	WINCH HANDLE
18	AC000_M000_003	MAST LOCKING PIN
19	AC000_M016_004	BUBBLE LEVEL
20	PFM08_C031_139ZN	LOWER PROTECTION FOR SPIRAL CABLE
21	AS000_M000_005	MAST SECTION ANGULAR GUIDE
22	PFI08_C031_012ZN	MAST SECTION ANGULAR GUIDE REINFORCEMENT

BASE STRUCTURE_BASAMENTO_ESTRUCTURA BASE



N.	CODE	DESCRIPTION
1	DLINE_C003_038	TOW BAR INFERIOR PLATE
2	AC000_M000_081	BUNDED TANK DRAIN CAP
3	AC000_M000_026	STABILIZER CLAMP
4	AC000_M000_139	TOW BAR STABILIZER
5	DLINE_C003_037	TOW BAR UPPER PLATE
6	AC000_I025_264	OIL DRAIN CAP
7	AC000_I025_005	PIPE FITTING
8	AC000_I005_007	PLASTIC FUEL TANK
9	TF8K1_C000_0014ZN	BATTERY LOCKING PLATE
10	DLINE_C000_011	BATTERY PLATFORM
11	AC000_E046_007	BATTERY
12	XECOK_AS05_009	FUEL TANK PLATE GASKET
13	AS000_M016_070	FUEL LEVEL INDICATOR
14	AC000_M000_014	FUEL FILLER CAP
15	DLINE_C005_023	FUEL TANK PLATE
16	XNOVA_C004_001	BASEMENT
17	AC000_P037_025	MUDGUARD
18	XSTAE_C003_005	AXLE
19	AC000_M000_042	WHEEL
20	DLINE_C005_089	FUEL TANK LOCKING PLATE
21	XSTART_C003_301	TOW BAR PIN
22	AC000_M000_079	COTTER PIN
23	AS000_M036_084	RETENTION ROPE
24	XSTART_C003_426	INFERIOR TOW BAR
25	XMI2_C003_065	UPPER TOW BAR
26	XMI2_C000_004ZN	STABILIZER TUBULAR
27	AS000_M000_048ZN	LATERAL STABILIZER
28	AC000_M000_086	LATERAL STABILIZER LOCKING PIN
29	AC000_M000_090	FUEL LEVEL INDICATOR GASKET
30	DLINE_C005_042	FUEL TANK PLATE FRAME
31	XNOVA_C004_024	LIFTING REINFORCEMENT

CANOPY_CARENATURA_CARENADO



N.	CODE	DESCRIPTION
1	XNOVA_C008_011	RIGHT DOOR
2	AC000_M000_009	HINGE
3	XECOK2_M009_161	DOOR RETENTION ROPE
4	DLINE_C000_054	MUFFLER PROTECTION
5	XNOVA_C007_027	FRONT CANOPY
6	AC000_E018_002	CABLE GLAND PG21
7	DLINE_C007_051	EXHAUST GAS OUTLET PROTECTION
8	XNOVA_C007_028	FRONT GRID
9	DLINE_C035_026	MUFFLER
10	XNOVA_C008_013	LEFT DOOR
11	XRENT_C000_040	LOCK CONTRAST PLATE
12	XNOVA_C007_023	UPPER CANOPY
13	XSTA2_C036_109ZN	LIFTING EYE
14	AC000_M001_083	PLASTIC COVER
15	AS000_M036_083	PLASTIC COVER RETENTION ROPE
16	XNOVA_C007_005	REAR CANOPY
17	XNOVA_S010_041B	DATA PLATE
18	AC000_M000_017	LOCK WITH HANDLE

ENGINE_MOTORE_MOTOR



N.	CODE	DESCRIPTION
1	XNOVA_C000_003	ENGINE / ALTERNATOR SUPPORT
2	AC000_G001_001	OIL DRAIN PIPE
3	AC000_M038_014	ALTERNATOR SCREW
4	AC000_E034_020	ALTERNATOR
5	XECOK2_C001_007	ENGINE FRONT LEFT SUPPORT
6	AC000_M038_013	ENGINE SCREW
7	DLINE_C035_025	MUFFLER EXTENSION
8	AC000_M038_015	ENGINE SUPPORTS SCREW
9	XECOK2_C001_005	ENGINE REAR LEFT SUPPORT
10	AC000_M001_007	MUFFLER EXTENSION GASKET
11	K-1921511220	AIR FILTER ELEMENT
12	XECOK2_C001_458	AIR FILTER SUPPORT
13	K-1980572530	BELT
14	DLINE_C001_036	RADIATOR UPPER SUPPORT
15	DLINE_C000_032	RADIATOR FRAME
16	K-1553172402	RADIATOR RECOVERY TANK
17	B-BO_C001_120	BELT PROTECTION
18	X-RA_C001_019	FAN PROTECTION
19	K-1542632430	OIL FILTER
20	K-1522143170	FULE FILTER
21	XECOK2_C001_006	ENGINE REAR RIGHT SUPPORT
22	K-R140151352	AC PUMP
23	XECOK2_C001_236	RADIATOR INFERIOR SUPPORT
24	AC000_M001_008	FUEL PRE-FILTER
25	XECOK2_C001_008	ENGINE FRONT RIGHT SUPPORT
26	AC000_M033_017	ENGINE
27	AC000_M024_054	SHOCK ABSORBER

LINZ ALTERNATOR_ALTERNATORE LINZ_ALTERNADOR LINZ



N.	CODE	DESCRIPTION
1	L-U13CA114AV4	FRAME WITH STATOR
2	L-U13RA491B	ROTATING INDUCTOR
5	L-C13BT068D	TOP COVER
8	L-E13KA089D	FRONT COVER
10	L-E13VE000C	FAN
11	L-EX411668225	BEARING
16	L-E13KA045ACR	WIRED DIODE
18	L-E10KA012A	TERMINAL BOARD
21	L-EX541511025	25uF 550V CAPACITOR
22	L-E10KA109A	CAPACITOR CLAMP D. 40
38	L-E13GE211A	SAE DISCS 6 1/2
70	L-EYPM25IP68	CABLE GLAND
	L-EX431106008	WASHER
	L-E13GE210A	SPACER RING

CONTROL PANEL_PANNELLO DI CONTROLLO_PANEL DE CONTROL



N.	CODE	DESCRIPTION
1	AC000_E000_071	5 POLES CONNECTOR
2	AC000_E018_002	CABLE GLAND PG21
3	XNOVA_C019_017	CONTROL PANEL BOX
4	XNOVA_C019_019	INSTRUMENTS SUPPORT
5	AC000_E006_021	TERMINAL BOARD ELEMENT
6	AC000_E006_022	FINAL ELEMENT FOR TERMINAL BOARD
7	K-1569465990	KUBOTA LAMP TIMER
8	AC000_E000_040	RELAY 12V 30A
9	AC000_E012_027	LAMP SWITCH
10	X-MINI_C006_019	CIRCUIT BREAKERS FRAME
11	K-1524863590	STARTING SWITCH
12	XECOK2_C019_232	RIGHT STOP PLATE
13	AC000_E015_018	LIGHT BULB FOR WARNING LIGHT
14	AC000_E015_014	PREHEATER WARNING LIGHT
15	AC000_E000_037	CIRCUIT BREAKERS PROTECTION
16	AC000_E015_017	BATTERY WARNING LIGHT
17	AC000_E015_015	OIL WARNING LIGHT
18	AC000_E015_021	HOUR METER
19	XECOK2_C019_233	LEFT STOP PLATE
20	AC000_A039_157	CONTROL PANEL STICKER
21	XNOVA_C019_022	INSTRUMENTS PANEL
22	AC000_E012_028	13A RCD
23	XNOVA_C019_018	CIRCUIT BREAKERS SUPPORT
24	AC000_E014_005	ENGINE CONTROL PANEL
25	AC000_E012_013	12A CIRCUIT BREAKER
26	AC000_E011_007	230V 16A OUTLET
27	AC000_E006_051	STOP BUTTON
28	AC000_E006_053	STOP BUTTON RATING PLATE
29	AC000_E006_043	CONTACT SUPPORT
30	AC000_E006_052	STOP BUTTON CONTACT
31	AC000_M038_035	EARTHING TERMINAL
32	AC000_G006_003	24 POLES CONNECTOR


Kubota EPA ECU
ECU / EGV06 TycoAMP
DAS TP 0007
Actuator solenoid -
Actuator solenoid +
Coolant temp. sensor -
Coolant temp. sensor Sig
Speed sensor -
Speed sensor Sig
Speed sensor +12V
Battery charger alternator
Low pressure switch
Fuel pump
IG Battery charger alternator
Cranking
Preheating
Battery +
Battery -
XM m
Tav 4
10A Fuse
5A Fuse
10A Fuse
Ground
Preheating
Lamp Timer
Zetter 12V 40A
Start Switch
Emergency stop button
Battery Charger
Oil Pressure
Data : 09/04/2025
Autore : G.T.
Tavola : 1/4
Modello : X-NOVA-A0003
Codice : SE145A00003
Revisione : 0
TRIME


Alumen SB Linz alternator
Linz Alumen
Main winding
Excitation winding
Capacitor
XA f
Tav 2
PE
L
L1
L1
N
XA m
Tav 2
SQ1
RCBO
13A 30mA
1P + N
Floodlight switch
SQ2
SQ3
SQ4
SQ5
16A
SQ6
12A Circuit breaker
16A 230V
EEC socket
RL1
RL2
RL3
RL4
Tav 3
230V
Hour meter
Data : 09/04/2025
Autore : G.T.
Tavola : 2/4
Modello : X-NOVA-A0003
Codice : SE145A00003
Revisione : 0
TRIME


L1
L2
L3
L4
230V / 54V
Junction box
Coiled cable
Tav 2
Tavola : 3/4
Modello : X-NOVA-A0003
Codice : SE145A00003
Revisione : 0
Data : 09/04/2025
Autore : G.T.
TRIME


Kubota Z482E EPA
Actuator solenoid -
Actuator solenoid +
Coolant temp. sensor -
Coolant temp. sensor Sig
Speed sensor -
Speed sensor Sig
Speed sensor +12V
Battery charger alternator
Low pressure switch
Fuel pump
IG Battery charger alternator
Cranking
Preheating
Battery +
Battery -
Xm f
Tav 1
Actuator Solenoid
Sumtomo
Coolant Temp. Sensor
Tyco/AMP
Engine Speed Sensor
Yazaki
Low oil pressure switch
Fuel pump
Battery charger alternator
Starter motor
Preheat
12V Battery
Ground
AC000_E050_621
AC000_E050_626
Data : 09/04/2025
Autore : G.T.
Tavola : 4/4
Modello : X-NOVA-A0003
Codice : SE145A00003
Revisione : 0
TRIME